

mindo 123 Lounge and Dining collection

Design by Morten Bo Jensen

Dimensions



30.094 Dining table Ø 130 cm / 51.1" **H** 74 cm / 29.1" **Net/Gross weight** 31,4 kg / 36,4 kg **Volume** 0,37 m³ **Unit** 1 pc



30095 Dining chair incl. cushion **W** 59,5 cm / 23.4" **D** 68 cm / 26.7" **H** 81 cm / 31.8" **SH** 42,5 cm / 16.7" (excl. cushion) **Net/Gross** $\textbf{weight} \ 7.7 \ \text{kg} \ / \ 10.7 \ \text{kg} \ \textbf{Volume} \ 0.12 \ \text{m}^{\text{3}} \ \textbf{Unit} \ 1 \ \text{pc}$



30096 Lounge chair incl. cushion set W 76,5 cm / 30.1" D 88 cm / 34.6" H 75 cm / 29.5" SH 36 cm / 14.1" (excl. cushion) Net/Gross weight 12,6 kg / 16,6 kg **Volume** 0,2 m³ **Unit** 1 pc



30097 Side table Ø 50 cm / 19.6" **H** 42 cm / 16.5" **Net/Gross weight** 3,4 kg / 5,9 kg **Volume** 0,04 m³ **Unit** 1 pc

Colours



FRAME: Teak



PU Cord



CUSHION: ASH



mindo 123 Lounge and Dining collection

Design by Morten Bo Jensen

Materials & Care

TEAK is a hardwood well suited for outdoor use, whether oiled or left untreated. Mindo's teak comes from certified plantations, has not been treated and will acquire a grey patina over time. If the warm look of the teak is to be maintained, oiling with a suitable teak oil will be necessary before taking the furniture into use. The frequency required for such treatment depends on the climate the furniture is exposed to. Teak is a natural material; therefore, minor cracks and slight warping of the slats may be expected and are not a sign of inferior quality. Teak is easy to maintain as daily cleaning is simply brushing off loose dirt. Spills should be taken quickly, especially if the teak has not been treated. A mild dishwashing detergent and a soft brush or sponge in the direction of the grain will usually suffice. Always rinse the area well to remove any soap residue. Tougher stains might require light sanding. If treated previously, the treatment must be repeated after sanding the area. The teak slats can be removed and individually replaced if necessary.

POLYESTER is a popular choice for outdoor cushions due to its durability and weather resistance. It's resistant to mold and mildew, and with minimal maintenance, will maintain its vibrant appearance for many seasons. To care for the fabric, simply dust it regularly and clean stains using a mild soap solution with a sponge or soft brush. Rinse thoroughly to remove any soap residue and allow it to dry away from direct sunlight. Applying a fabric guard spray can help preserve polyester's excellent protective qualities over time.

The polyethylene **CORD** is a light, synthetic string, made to resemble traditional papercord, usually associated with mid-century Danish design furniture. The cord has excellent weather-resistant qualities, is durable and strong. Care and maintenance is minimal, an occasional wiping with a moist cloth is sufficient.

Storage & Covers

Teak outdoor furniture can be left outside year-round, but a furniture cover will protect it from dirt, leaves, and bird droppings, making spring cleaning easier. When using a cover, ensure good ventilation to prevent moisture buildup, which can cause dark spots or stains. Avoid letting a wet cover rest directly on the furniture and, weather permitting, regularly remove the cover to allow moisture to escape. Make sure furniture and cushions are completely dry before covering to prevent mold or mildew. For cushions, store them upright or slanted for maximum air circulation, with the backside facing up to protect visible areas from staining. Regularly checking the furniture and lifting the cover on dry days helps maintain its condition.

mindo 123 Dining table incl. chairs: Cover no. 5 mindo 123 Lounge chair incl. side table: Cover no. 1

Links

Mindo 123 Collection

www.mindo.com